

OVERHEAD ELECTRIC GUITAR Assembly Guide by

Assembly



1 Remove Headstock And Neck From Pockets & Assemble The Neck

* ensure strings aren't wrapped around the neck

Insert Assembled Neck Into The Slot And Click Into Place

* ensure strings sit properly in the saddle slots so your string spacing and action is correct.



3 Fully Tighten The Knob On The Back And Tune To Play

*tighten fully so there is no gap between neck and body to get the lowest action

Scan For FAQ & Guides

Demos & Guides



Journey FAQs



journeyinstruments.com

Disassembly



1 Unscrew Main Bolt Knob On Back

* if the bolt is tight, press neck against body with other hand while untightening the knob. Changes in humidity or temp can make joint tight

2 While Holding Neck, Press Black Button with Thumb

*if bolt isn't unscrewed fully, unscrew back bolt further for the latch to disengage
* If it's hard to press, push neck against the body with other hand



3 Place Body In Case, Detach Headstock And Neck

* if you've removed the headstock pocket for assembled carry, insert it after guitar body is in position

Put Headstock & Neck In Pockets, & Put Panel On Top

* headstock pocket position as shown
*secure strings on top with velcro tab to protect finish



5 After Zipping Guitar Case, Place Neck In Laptop/Cargo Area

*there's an elastic chord to the right of the computer pocket to hold neck sleeve in place

Assembled Carry



1 Slide Neck Sleeve Over Guitar Neck & Unzip Case Top Zipper

* top zipper opening is for neck sleeve to slide through
*the long flap on the neck sleeve should face forward

2 Slide Assembled Guitar W/ Neck Sleeve Through The Slot

*place panel behind neck sleeve
*remove headstock pocket if carrying assembled guitar



3 Zip The Guitar Case Shut And Clip Outside Straps

*Velcro should secure neck sleeve
*place headstock pocket in cargo area
*if raining, pack guitar disassembled & use rain cover

Register Your Guitar Or Contact Us Anytime

Register Guitar



Contact



Search "Journey Instruments" to find us on social media:

